

Front

2. When you are in FM Mode, short press "+" or "-" to next or previous channel, long press "+" or "-" to volume plus or minus.

TF Card

1. While the headphone is on, insert the TF card, headphone will enter into TF mode directly.
2. When you are in TF card Mode, short press "+" or "-" to next or previous channel, long press "+" or "-" to volume plus or minus.
3. After you take out the TF card, the headphone will swift to FM mode.
4. If you want to go back to the Bluetooth mode, short press the mode button, headphone will be re-paired when the bluetooth of your device is also on.

Charging

To charge the headphone, connect the charging cable into headphone micro USB, the LED will light red while charging. When fully charged, the LED will light off.

Specification

Model	1549
Product Dimension	17.0x17.0x8.0cm
Product Weight	210g
Bluetooth Version	V5.0
Talk/Play Time	> 5.5 hours at 50% volume
Charging Time	< 2.5 hours

Safety Instruction

- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- Do not expose the headset containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).

Environmental Friendly Disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.



Instructions

1549 Moyoo Essence Wireless Headphone

Please read this manual carefully before using the product and keep it for future reference

Back

- ENG Foldable bluetooth headphone with built-in microphone.
- DE Faltbarer Bluetooth-Kopfhörer mit integriertem Mikrofon.
- NL Opvouwbare bluetooth koptelefoon met ingebouwde microfoon.
- SWF Fällbar Bluetooth-hörlurar med inbyggd mikrofon.
- FR Casque Bluetooth pliable avec microphone intégré.
- ES Auricular bluetooth plegable con micrófono incorporado.


Product Overview



Headphonex1



USB Charging Cablex1




Audio Cable x1



Manuax1

Brief Instruction



① TF slot	⑧ Audio 3.5mm jack
② Mode Button: Bluetooth /FM	⑨ Microphone
③ Next Song (short press)/ Volume+(long press)	
④ Previous Song (short press)/ Volume-(long press)	
⑤ Multi-Function Button (MFB): ON/OFF/Play/Pause	
⑥ LED light	
⑦ USB charging port	

Bluetooth Connection

1. Make sure the audio cable is not contacted with the headphone.
2. Press MFB button for 2 seconds till you hear "Power On".
3. After power on, headphone LED light will flash red and blue alternately and then enter into "Bluetooth Mode" automatically.

4. Ensure the bluetooth connection on your device is on, select the "Moyoo Essence Headphone" and connect.
5. After the initial paring, the headphone will automatically connect to the last connected device when it is turned on again.

Call Handling

1. When there is an incoming call, you can simply short press the MFB button on the headphone to answer the phone call or long press the MFB button to reject the calling.
2. During the phone call, you can short press the MFB button to ending the call and long press "+" or "-" button to plus or minus volume.
3. Short press twice MFB button you can redial last contact number.

Aux In

1. When the headphone is off, connect the headphone and your device with the 3.5mm audio cable in the package.
2. When the headphone are under other modes, plug the 3.5mm audio cable in, headphone will enter into Aux in mode directly.

FM Function

1. Short press Mode Button to swift the Bluetooth Mode to FM Mode, you can hear a hint tone" FM Mode" and the LED light flash blue.